




# Motorola C350 Ear Speaker Replacement

Use this guide to replace the earpiece speaker in your Motorola C350.

Written By: Vincent Monteil



## INTRODUCTION

Use this guide to replace the earpiece speaker in your Motorola C350.

---



### TOOLS:

- [T6 Torx Screwdriver](#) (1)
  - [Metal Spudger](#) (1)
-

## Step 1 — Rear case freeing



- Use your finger to press the button and free the device rear case.
- ⓘ You may have to force it a bit more to free its bottom if you open it for the first time.


## Step 2 — Removing battery



- slide the black button to free the battery so you can grab it with your other hand.





### Step 3 — Separating the front case



- You will see one plastic clip on each side of the device. Use your thumbs to push them apart and being able to separate the front case from the device other components.

### Step 4 — Ear Speaker



- Remove the four T6 Torx Screws

## Step 5



- Use a metal spudger to gently free the screen/ear speaker metal case.

## Step 6



- Slowly peel the ear speaker off the case.
- ⚠ Be really careful about the small plastic pin which can be easily lost.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-18 11:31:19 PM.